


Retain an inspected wood floor and keep its edges visible

96 x 120 in clear interior. Same scale in each panel; no surveyed condition or capacity is implied.

01 / EXISTING

Front door: 36 in




96 x 120 in clear

1. Storage
2. Bench

02 / CONDITION TO ADDRESS

Front door: 36 in




96 x 120 in clear

- Inspect wood perimeter
Retain only on the stated basis

03 / PROPOSED ARRANGEMENT

Front door: 36 in



96 x 120 in clear

1. Feed
2. Water + tray
3. Nests
4. Side roost

Rehearse before fastening

CONDITION-SPECIFIC DETAIL

Keep the floor-to-wall perimeter and any liner edges accessible for inspection. A loose, removable spill tray stays beneath the water container; it is not a waterproof floor assembly. Lift it to inspect and dry both faces before resetting.

Example positions are not structural opening, drainage, attachment or animal-housing approval. See the PDF for work order.

Example overview. Following pages contain its conditional work and material scope.

EXAMPLE: Retain an inspected wood floor and keep its edges visible


Current unsaved inputs

Measured preparation and quote scope. Unknowns and work holds are retained. This worksheet does not design structural alterations. All dimensions are inches.

1. Existing condition and measured room

Wood floor / condition established

Example condition: floor and supporting shell have been checked and no unresolved movement, decay or moisture remains. The existing 36 in door and its closure are retained. Cleaning uses a method compatible with the actual wood assembly.



96 x 120 in clear

Door: front; offset 30 in; usable opening 36 in. Empty measured room; no furniture, height or swing is inferred.

Loaded container width: 24 in. 12 in width difference only. Rehearse handles, door swing, approach and turning with the actual load; this is not a route pass.

Retain: Retain the shell and floor only where their actual condition and suitability are established. Keep the existing service door if the loaded clean-out container fits.

Adapt: Remove portable storage from the care route. Choose a floor-compatible cleaning method and fit removable nests and roosts to confirmed backing. A liner must leave its edges and the base inspectable.

Resolve: Floor underside, recurring wet edges, proposed opening framing and fitting attachments. A dry-looking

top face is not a condition check.

Opening: retain. Existing opening retained in this declared example. Actual closure and backing need inspection.

Floor: retain. No covering quantity calculated. Bedding and any repairs remain separate.

2. Work in dependency order

01. Measure the shell and the real route

Measurements recorded / rehearse on site

Measure clear wall faces and both sides of the floor where accessible. Record door stops, leaf motion and loaded containers; the outside shed size is not the usable room.

Continue when: The sketch distinguishes measured facts from assumed positions; each unknown has a named measurement or decision.

02. Resolve shell, moisture and service work

Condition basis recorded / verify scope

Document the basis for retaining wood and its support. Resolve recurring dampness and damaged edges before covering or attaching fittings; retain an inspection path to seams.

Continue when: The relevant repair and alteration scope is recorded; affected work does not proceed on a layout assumption.

03. Rehearse the interior before fastening

Rehearse before fastening

Tape the feed, spill tray, nest and removable-roost footprints. Carry your measured loaded container to the centre lane, then through the held-open door; check height and weight separately.

Continue when: The door works, supplies remain accessible and cleaning can reach each intended floor area with the actual tools.

04. Complete reviewed openings and enclosure work

Follow the recorded opening decision

Keep the existing openings in this example. Reconcile closure, weather edges and the actual fitting backing before selecting fasteners. A new bird opening is a separate wall-specific design.

Continue when: Openings, attachments and weather transitions match their recorded decisions; no generic sketch is being used as a structural detail.

05. Fit the interior and organize supplies

Use confirmed backing and selected fittings

Install only the agreed removable fittings. Keep tray and liner edges accessible; do not use a moisture-tolerant top layer as permission to hose the wood base.

Continue when: Fittings are secure and removable as intended; a refill or clean-out does not require dismantling a structural element.

06. Run the complete care sequence

Test after earlier work; no occupation approval

Lift the tray and fittings, inspect the exposed wood, clean and dry using the compatible method, then return each item. Record recurring wet points and the next inspection.

Continue when: The setup supports the actual care routine, with the date and unresolved follow-up written beside the sketch.

3. Owned, needed and awaiting a quote

Your statuses do not override repair or opening holds. No cost total is added to another project budget.

C01. Shell, floor and moisture repairs

Status: Unresolved. Quantity basis: Separate measured repair scope

Retain the checked wood base and shell; quote any newly discovered repair separately.

Your quantity / product / quote: Retain the checked wood base and shell; quote any newly discovered repair separately.

C02. Opening framing and backing

Status: Unresolved. Quantity basis: Reviewed opening / attachment detail

Existing doorway retained; identify actual studs or blocking for fitting mounts. No new header in this scope.

Your quantity / product / quote: Existing doorway retained; identify actual studs or blocking for fitting mounts. No new header in this scope.

C03. Protected air openings and closures

Status: Unresolved. Quantity basis: Measured opening + selected assembly

Price only measured closure and protected-air changes after reviewing existing openings.

Your quantity / product / quote: Price only measured closure and protected-air changes after reviewing existing openings.

C04. Removable nests and roosts

Status: Unresolved. Quantity basis: Selected units / member lengths

One removable side roost and one nest unit in the example; measure the actual unit and mounting hardware before purchase.

Your quantity / product / quote: One removable side roost and one nest unit in the example; measure the actual unit and mounting hardware before purchase.

C05. Floor protection and bedding

Status: Unresolved. Quantity basis: Measured usable floor / product pack

No covering quantity calculated. Bedding and any repairs remain separate. No whole-floor covering assumed. Price optional removable spill tray, chosen bedding and any compatible edge treatment separately.

Your quantity / product / quote: No whole-floor covering assumed. Price optional removable spill tray, chosen bedding and any compatible edge treatment separately.

C06. Feed and water equipment

Status: Unresolved. Quantity basis: Selected equipment footprint

Reuse or select portable feed/water containers; include loaded handles, lid and tray footprint.

Your quantity / product / quote: Reuse or select portable feed/water containers; include loaded handles, lid and tray footprint.

C07. Outdoor enclosure and bird connection

Status: Unresolved. Quantity basis: Separate site sketch and quote

Measure a separate outdoor enclosure, gate and bird connection. Retaining the wood floor and service door does not establish run size, mesh, ground closure or a new wall opening.

Your quantity / product / quote: Measure a separate outdoor enclosure, gate and bird connection. Retaining the wood floor and service door does not establish run size, mesh, ground closure or a new wall opening.

C08. Delivery, disposal, tools and services

Status: Unresolved. Quantity basis: Itemized project costs

Measure waste carrier, outside staging and disposal route; no fixed container volume is assumed. Obtain any required shell/attachment advice separately; retained items are not charged again.

Your quantity / product / quote: Measure waste carrier, outside staging and disposal route; no fixed container volume is assumed. Obtain any required shell/attachment advice separately; retained items are not charged again.

4. Project notes and revision context

DECLARED EDITORIAL EXAMPLE v2.0.0. Keep the floor-to-wall perimeter and any liner edges accessible for inspection. A loose, removable spill tray stays beneath the water container; it is not a waterproof floor assembly. Lift it to inspect and dry both faces before resetting.

Rehearse this arrangement after the stated condition is established.

The measured layout is transferred when you download its JSON. Later worksheet and editor changes remain separate; compare clear dimensions, doorway and date before ordering. A backup of this worksheet and its material CSV are also attached to this PDF.